

### 1. Check Contents

Shower Kit

- x1
- x1
- x2
- x2
- x1
- x1
- x3
- x4
- x7
- Fitting Instructions x1
- Battery x2
- Guarantee Card x1
- Ceiling fed Arm & Rose x1

### 2. Position Mixing Valve

Not in Zones 0-2

E.g. Under a bath

E.g. In a loft area

E.g. Maximum distance 10 metres

### 3. Install Mixing Valve

COLD

HOT

OUT

### 4. Install Shower Kit / Rose

### 5. Check Pairing of Wireless Controller and Mixing Valve

Power on Mixing Valve

Mixing Valve light is green. Wait 30s turns yellow.

Turn Wireless Controller on.

When wireless connection made Mixing Valve light turns green.

### 6. Install Wireless Controller

Lock

Align

Unlock

### 7. Check Operation

BRISTAN

38

Temperature Control

- Hot
- Cold
- Low battery warning light

Flow Control

- Eco Water saving mode
- Low Flow
- Medium Flow
- Full Flow